



SIMUDRIVE SD100Hz

- FR** Manuel d'installation Illustrations
- EN** Installation Guide Illustrations
- DE** Abbildungen Installationsanleitung
- NL** Illustraties in installatiegids
- PL** Rysunki instrukcji instalacji
- CS** Obrázky Návodu k použití
- RU** Иллюстрации к инструкции по монтажу
- AR** رسومات دليل التركيب


1



2




3




4


[1]




[2]






5




6







10




11



12




13





14

A

1)



2)




3)



P3 = 1

B

1)



2)



3)


P3 = 2

15

1)








2)




3)

P3 = 3







21




22




23



24



25





SIMU

Z.I. Les Giranaux

70100 Arc-Les-Gray

FRANCE

www.simu.com



5153751A

S.A.S. au capital de 5 000 000€-Z.I. Les Giranaux-70100 Arc-Les-Gray -FRANCE -RCS VESOUL B 425 650 090 -SIRET 425 650 090 00011 -n°T.V.A CEE FR 87
425 650 090 - 21/04/2020 - Images not contractually binding